## **LED Vapor Fixture**

# **Vapor Fixture**

#### **Product Description**

VaOpto's LED Vapor Tight Fixture without ballast is wire and lampholder ready for two LED T8 tubes, which replaces tradional vapor tight fixture, and also an energy-efficient, leadfree, UV-free, and long-lasting cold lighting fixture.

#### **Product Information**

- Power input: 100-480VAC, 50/60Hz
- IP65

- Weight: 2.7 kg (6 lbs)
- Lens and Base Material: PC
- 5-year limited warranty
- Hasp: PC
- cULus: E335469
- Hook material: Stainless Steel

### **Ordering Information**

Part# VO-TF-07W4-2


#### Installation


- 1. Disconnect the power before installation.
- Drill the fitting holes at the place of installation (wall/ceiling), make sure, that no 2. cables or other lines are passing in place of drilling.
- Put the screws in the holes and fix the lamp to the mounting place. 3.
- Insert the installation cable, which is suitable for the installation, through the 4. washer in the hole (4). (By slightly pulling, the position of the washer can be optimized.
- Connect the cable end with the saddle (5) at the connecting plate. Pay attention 5. to the correct polarity.
- Adjust the connecting plate (7) 6.

DESIGNLIGHTS

LED Manufacturer

- Insert the luminaire into the holder (8) and turn it at 90° until it registers. 7.
- 8. Assemble the clamps (11) at the designated position
- 9. Put on the cover (10) and fix it with the clamps (11). All clamps should be used.





Illuminating

american

lighting association

₫

COLUS C SUS FC RoHS lighting







#### **Safety Instruction**

- For LED Tube Use Only 1.
- 2. Electrical works have to be done by certified electrician.
- In case of damages, disconnect the lamp from 3. the power. Do not try to repair the lamp on your own. Repair has to be done by certified electrician.

